



## MULTIPURPOSE RANGE

BEAUTY IS ONLY SKIN DEEP,  
IT'S WHAT'S INSIDE THAT COUNTS

PRODUCT: MP100



# AIRsteril<sup>®</sup>

**T:** 01234 871 875

**E:** [sales@airsteril.co.uk](mailto:sales@airsteril.co.uk)

**W:** [www.airsteril.co.uk](http://www.airsteril.co.uk)



**CLEAR EMBARRASSING ODOURS QUICKLY TO  
KEEP ALL ROOMS CLEAN, FRESH AND IN  
FULL WORKING ORDER**

### REMOVE ODOURS, CONTROL INFECTION & IMPROVE HYGIENE

- Reduces harmful viruses
- Breaks down unwanted bacteria
- Quickly clears odours
- Cleans into fabrics and furnishings
- Stops Mould and fungi growth
- Treat multiple areas with a single unit
- No chemical residue or moisture after treatment
- Area can be put back to full use within minutes
- Low maintenance, clean and lamp change once a year



#### › ODOUR PROBLEMS

Unpleasant lingering odours can leave some rooms unusable or create a negative impression which affects your company image and customer feedback. Attempting to mask odours with fragrances can make the area even more unpleasant.

Many odours are created from microorganisms, musty odours can indicate mould whereas unpleasant stale odours may be a warning sign of high levels of bacteria. Traditional cleaning and disinfecting will not eliminate odours, you cannot clean the air itself and even simple odours from food, illness or smoke can remain in an area for days if untreated. Methods such as fogging can increase damp issues or leave chemical residues, often meaning areas cannot be occupied for several hours.

The MP100 unit offers a rapid, mobile solution to odour issues, with many odours cleared in minutes.

#### › BENEFITS OF USING AIRSTERIL MP100

- › Rapidly clear embarrassing odours from smoke, food, illness, incontinence, damp and mould
- › Perfect for a wide variety of unoccupied areas
- › Hotels – bedrooms, conference rooms
- › Offices – meeting rooms, break room, cafeteria
- › Healthcare – communal areas, smoking rooms
- › Gyms – studios, changing areas, washrooms

Guideline Treatment Times To Clear	20m <sup>2</sup>
Body odour / stale air	15 minutes
Mild smoke odours / food odours	30 minutes
Sickness odours / incontinence odours	1 hour
Strong persistent odours*	4 hours+

\*Odours engrained in fabrics/furnishing will require longer or repeated treatments to clear. Contact us for a specific guide.



RAPID ODOUR CLEARANCE IN UNOCCUPIED AREAS TO MAINTAIN A PROFESSIONAL ENVIRONMENT, AND ENSURE POSITIVE REVIEWS FROM ALL



### › SERVICING AND MAINTENANCE

Power must be disconnected before attempting any servicing and only undertaken by a competent individual. All AIRsteril partners have fully trained engineers to carry out all servicing work. The MP cover is easily removed by taking out four screws from the cover, then the two finger screws removed from the lamp housing plate to allow lamp replacement. Any dust or debris build up should be cleared from the interior. Lamps must be changed on an annual basis to maintain performance.

### › HOW OUR MULTIPURPOSE SYSTEM WORKS

All AIRsteril units utilise our unique combination of 5 technologies. They eliminate unpleasant odours and control harmful bacteria and viruses 24 hours a day, 365 days of the year. The MP100 is designed for rapid odour clearance and microbial reduction. Its portable design, allows quick re-location to resolve odour issues around the building, or just to quickly freshen each room as part of the cleaning cycle.

Due to its high power each room should be unoccupied during treatment as it would be unpleasant to remain in the area. Once treatment is over the unit should be switched off unit and allow natural ventilation for 15-20 minutes to ensure the environment is now pleasant to occupy and all odours are eliminated. Units should be mounted as high as practical for best operation, the higher the unit, the faster odours will be cleared.

## ODOUR ELIMINATION GUARANTEED

\*Conditions Apply



## TECHNICAL DETAILS

### Multipurpose Unit Dimensions

750mm (l) x 130mm (w) x 100mm (d)

### Power Supply

220-230V 38 watts

### Set Up

Usually free standing as high as possible for maximum dispersal and quickest effect. Can also be wall or ceiling mounted if required.

### Construction

Anodised aluminium, solid extrusion.

### Weight

3.4kg

### Operation

As required for odour clearance, or continuous use for areas over 100m<sup>2</sup>. Requires annual lamp change.